

Bribie Wall Shower Hot & Cold

Installation Instructions

Before you start; a ½" Double screwed outlet must be pre-installed behind the wall which is connected to both hot water left hand side & cold water right hand side as you stand facing the wall.

The Double screwed outlet consists of 2 x ½" male threads about 250mm apart.

1. Turn off mains water supply.
2. Remove any caps exposing the threads, these may need to be cut back to leave 10 - 15mm protruding from the wall.
3. Clean thread on outlet of old thread tape etc.
4. Slide cover plates over threads protruding from wall, apply liquid thread tape on threads. Screw on new shower tap until tight and ¾" thread is in the horizontal position. You will need to back off a little on both sides so the breech tubing can be fitted in between.
5. Cutting the breech tube to length.
Take a measurement between both threads on Tap bodies and add 20mm to full length.
Measure and trim/cut both sides of breech tubing with a tube cutter to correct size.
6. Fit the breech tube between taps, making sure the service nuts and olives are in place.
Tighten service nuts on breech tubing.
7. Slide on standoff clip up from the bottom of the shower pipe (Straight end)
8. Slide on service nut and nylon olive to bottom of the shower pipe.
9. Fit shower pipe onto breech tube and secure loosely with service nut. If shower rose is too high then remove from tap and cut shower tubing to length using a tube cutter. (Shower rose face should be approximately 2 metres – 7' from ground level.)
10. Position shower pipe in place checking pipe is vertical with a level, position standoff clip about ¾ up the pipe just below bend. Mark holes on wall for screws using the standoff clip as a template. Drill holes using a 6mm masonry drill and tap in red plugs into wall, reposition shower tube and then screw in stainless screws through standoff clip.
11. Tighten service nut & nylon olive at bottom of shower pipe. Turn on mains supply and flush pipes checking for any leaks. Attach shower rose to bent end of shower pipe.
12. Clean your new stainless steel shower with a Hillmark Steelkleen wipe. These wipes are designed to remove finger prints, water marks and prevent brown staining. Should brown staining occur use a wet (Scotch Brite) green pot scourer with dishwashing detergent and rub up & down the shower. To keep your shower looking good wipe over your shower regularly with Steelkleen Stainless Steel spray (purchased through most supermarkets). We use 316 Stainless Steel which doesn't rust.

Thank you for purchasing a Rainware Pool Shower, your shower is now ready to use.

Warning: If the shower is in direct sunlight this could cause the water held in the shower or garden hose connecting the shower to heat up and cause scalding. Please ensure before using the shower to let water run for a few moments to washout any overheated water.

Rainware Pty Ltd: Phone 0754 926 200

Mobile 0411 660 933

Fax 0754 926 788

Email admin@rainware.com.au